## Symbols for sash adjustment when installed

These symbols facilitate quick orientation when completing the following steps to adjust the window sashes after installation. Use a 4 mm Allen key as the tool.



Height adjustment



Lateral adjustment




Gasket compression adjustment




#### NOTE!

Adjusting Roto hardware components may only be carried out by authorised and qualified personnel.






Lateral adjustment



Gasket compression adjustment

# Adjustment instructions

Pivot rest / corner hinge – hinge-side K




Height adjustment Lateral adjustment

### Adjustment instructions

Locking cam





The following symbols show the different handle positions and the resulting sash positions of windows and balcony doors.

Handle position	Sash position	Symbol	Meaning
			Closed sash position.
			Sash turned open position.
			Sash tilted open position.
	•	k	Incorrect sash position.

### Operation information for end users

Handle positions of Tilt&Turn hardware



The following symbols and signs can be positioned on windows and balcony doors to protect the end user.

Please order labels separately (OPR\_14\_DE-EN\_v1).



